

User manual



V1.1

Print from Smart Photo Print app





Print the images in your Smartphone using the Smart Photo Print app.





1

Install the Smart Photo Print app in your Smartphone from the online stores (Only available for iOS and Android).




android ➔ <https://play.google.com/store/apps/details?id=com.iboomobile.mitsubishi&hl>

 **iOS** ➔ <https://itunes.apple.com/app/kiosk-prints/id560637995?mt=8>

2

Go to your Smartphone WiFi settings and select the SmartPhotoPrinter SSID: **#PhotoPrint**





android

3

Open the SmartPhone photo gallery and select the image or the images that you want to print.




4

Click on the “share” button and then the Smart Photo Print app icon to launch Kiosk Print.




5

On the launched Smart Photo Print app, select the photo size for each one of the selected images, and then click on **CONTINUE**.




6

Wait until the images are sent to the SmartPhotoPrinter



7


Check your order number. It could be necessary to pick up your printed photos !!!






iOS iPhone / iPad


3

Open the iPhone/iPad photo gallery / Camera Roll and select the image that you want to print. Then Click  to send it.




4

Click on the Smart Photo Print app icon to launch Kiosk Print app.




5

On the launched Smart Photo Print app, select the photo size for each one of the selected images, and then click on **CONTINUE**




6

Wait until the images are sent to the SmartPhotoPrinter



7

Check your order number. It could be necessary to pick up your printed photos !!!





- <http://www.mitsubishielectric-printing.com>
- <http://www.messec.net>